

Install Guide for Foamsorption

The installation of all Foamsorption tiles is simple and quick making the cost of installation extremely low. Foamsorption tiles are simple to cut with a sharp knife and glued into position with our special adhesive.

Foamsorption adhesive allows for accurate alignment and location of tiles. A 5mm shadow gap should be left between the tile joints which help to give a perfect optical impression. Clean gloves are advisedly worn when handling and installing the tiles.

1. Make sure both the tiles and the surface to which the tiles are being applied are free from dust and dirt.
2. Cut the end of the adhesive tube to produce a bead.
3. Place the Foamsorption Tile pattern side down on a clean, flat surface.
4. Apply a bead of adhesive along all four edges of the tile.
5. Apply three more beads of adhesive within the tile area
6. Immediately press the tile against the surface it is to be adhered to and position as required.

FOAMSORPTION acoustic tiles are produced in pairs, i.e. handed positive and negative. When bonding these tiles, start in the centre of the area and work outwards. Each row should commence with the opposite hand than its predecessor and alternate from row to row.

FOAMSORPTION acoustic tiles should be stored in a completely dry and room temperature environment. They are designed for installation under standard occupancy conditions from 10-25oC and not more than 60% RH in an enclosed building.

The contractor shall be responsible for the examination and acceptance of all conditions and project suitability prior to the acoustic tile installation.

EST. 1969

Crawley Mill, Dry Lane, Witney, Oxfordshire, OX29 9TJ
sales@soundservice.co.uk

VAT NO: GB 434 5018 73 REG NO: 960986



Tel: 0845 363 7131
Fax: 01993 779569