

## **Install Guide for Photosorption**

Photosorption sound absorbing panels are simply bonded to the walls with our special aerosol adhesive.

The panels and adhesive must be kept and stored inside at normal room temperature at all times and fully acclimatised in the area they are to be installed for at least 24 hours before fixing. To avoid soiling the diffusers, it is advised cotton gloves are worn when handling them. The substrate must be clean, flat, dry and free from oil, dust and grease or any other residue that could affect the bonding of the panels.

The adhesive comes in easy to use aerosol cans and is applied to both surfaces and an immediate bond is obtained when they two surfaces are pressed together. More instructions are on the can. Pressure must be applied evenly over the panel upon contact; care must also be taken not to damage the face of the diffuser by pushing too hard.

**We strongly recommend a test adhesion is conducted before proceeding with full installation.**

**Every effort is made to ensure the information given here is accurate and reliable but is to be used only as guidance. As each application can be different, users are advised to conduct their own tests to confirm suitability. As our policy is one of continuous development and improvement, we reserve the right to make changes without prior notice.**

EST. 1969

**Crawley Mill, Dry Lane, Witney, Oxfordshire, OX29 9TJ**  
**[sales@soundservice.co.uk](mailto:sales@soundservice.co.uk)**

VAT NO: GB 434 5018 73 REG NO: 960986



**Tel: 0845 363 7131**  
**Fax: 01993 779569**